



YAMAHA

Owner:

Engine hours:

Engine id:

F225F / F250D / F300B

FL225F / FL250D / FL300B

YAMAHA MAINTENANCE CHART

Item	Remarks	Initial		Every			Ref. page service manual	OK ✓
			20h	100h Every 1 year	300h 3 year	500h 5 year		
TOP COWLING								
Cowling lock lever and water leakage	Check			•			10-7 10-14	
FUEL SYSTEM								
Fuel hoses (high / low pressure)	Check / replace			•			6-1	
Fuel filter engine (water separator)	Check / replace		•	•			6-12	
Fuel filter (after vapor separator)	Check / replace			•			6-26	
Fuel pump	Check / replace				•		6-30 6-40	
POWER UNIT								
Ignition coils / ignition coil leads	Check / replace		•	•			5-46	
Engine oil	Replace API: SE,SF,SG,SH,SJ eller SL SAE 5W-30,10W-30, 10W-40 Amount: Without filter 6,0 liter With filter 6,3 liter		•	•			10-8	
Oil filter	Replace			•			10-9	
Oil control valve filter	Replace					•	10-12	
Timing belt (*2)	Check / replace			•			7-37 7-39	
Valve clearance	Check / adjust Intake: 0,205 ± 0,035 mm Exhaust: 0,345 ± 0,035 mm					•	7-2 7-4	
Spark plugs	Check / replace NGK LFR6A-11			•			7-48	
Thermostat / PCV	Check / replace			•			7-72	
Engine starting condition / engine idle speed / noise	Check		•	•			10-5 10-8	
Fuel / oil leak	Check / replace		•	•			6-1	
Exhaust guide / manifold (*4)	Check / replace						9-20	
CONTROL SYSTEM								
	Check / adjust / replace		•	•				
YDIS (*5)	Check			•				
Yamaha meter / gauge (Resetting maintenance intervals) Lan and Premium Lan	Check See "6Y8 and 6Y9 set up manual"		•	•				
POWER TRIM AND TILT								
PTT unit	Check / adjust / replace		•	•			10-14	

[illegible]