



YAMAHA

Engine number:

Operating hour:

F4B, F5A, F6C 10- YAMAHA MAINTENANCE CHART

Item	Remarks	Every		Every		Ref. page service manual	OK ✓
		20h	100h Every 1 year	300h Every 3 year	500h Every 5 year		
TOP COWLING							
Cowling lock lever	Check	•	•			10-11	
FUEL SYSTEM							
Fuel hose	Check / replace	•	•			6-1	
Fuel strainer	Check / replace	•	•			6-6	
Fuel tank	Check		•			6-6	
Fuel pump	Check / replace			•		6-22	
POWER UNIT							
Engine oil	Change: API: SE,SF,SG,SH,SJ eller SL SAE 5W-30, 10W-30, 10W-40 Amount: 0,6 liter	•	•			10-8	
Valve clearance	Check / adjust Intake: 0,08 - 0,12 mm Exhaust: 0,08 - 0,12 mm				•	7-2	
Spark plugs Spark plug cap	Check / replace NGK CR6HSB		•	•		7-35 5-5	
Fuel / oil leakage	Check			•		6-1	
Thermostat	Check / replace		•			7-35	
Engine idle speed / noise	Check			•		10-7	
Engine starting condition/noise	Check	•	•			10-6	
Cooling water leakage	Check	•	•			10-7	
Pilot water	Check	•	•			10-3	
Upper case (*1)	Check / replace					9-12	
CONTROL SYSTEM							
Throttle / shift cable and links	Check / adjust / replace	•	•			6-14 8-16 9-11	
Engine shut-off switch	Check / replace		•	•		10-4	
Start in gir protection	Check / adjust	•	•			-	
LOWER UNIT							
Gear oil	Change: SAE 90/API GL-4/5 Amount: 100 cm³	•	•			10-9	
Water inlett	Check	•	•			10-7	
Propeller	Check / replace	•	•			8-4	
Impeller (*2)	Check / replace		•	•		8-6	
GENERAL							
Anodes	Check / replace		•			7-35 8-4	
Battery	Check / replace / charge	•	•			10-3	
Wiring harness connections and coupler connections	Check / adjust	•	•			-	
Bolts / nuts	Check / adjust	•	•			-	
Greasing points	Lubricate		•			10-10	
NOTES: (*1) Every 1000 hours (*2) Replace Impeller every 300h / 3 year IMPORTANT! Ref: service manual 6BV-28197-3M-11 Always check servicemanual and TSI for information!							