



YAMAHA

Owner:

Engine hours:

Engine id:

**F150G F175A F200F / F200G
FL200F / FL200G****YAMAHA MAINTENANCE CHART**

Item	Remarks	Initial		Every			Ref. page service manual	OK ✓
			20h	100h Every 1 year	300h 3 year	500h 5 year		
TOP COWLING								
Cowling lock lever and water leakage	Check			•			10-17	
FUEL SYSTEM								
Fuel hoses (high / low pressure)	Check / replace			•				
Fuel filter engine (water separator)	Check / replace		•	•			6-10 6-11	
Fuel filter (after vapor separator)	Check / replace			•				
Fuel pump	Check / replace				•		5-27	
POWER UNIT								
Ignition coils / ignition coil leads	Check / replace		•	•			5-46	
Engine oil	Replace API: SE,SF,SG,SH,SJ eller SL SAE 5W-30,10W-30, 10W-40 Amount: Without filter 4,3 liter With filter 4,5 liter		•	•			10-9 10-10	
Oil filter	Replace			•			10-12	
Oil control valve filter	Replace					•	10-14	
Timing belt (*2)	Check / replace			•			7-21 7-22	
Valve clearance	Check / adjust Intake: 0,17 - 0,24 mm Exhaust: 0,31 - 0,38 mm					•	7-2	
Spark plugs	Check / replace NGK LFR6A-11			•			7-35	
Thermostat / PCV	Check / replace			•			7-68	
Engine starting condition / engine idle speed / noise	Check		•	•			10-9	
Fuel / oil leak	Check / replace		•	•			10-3	
Exhaust guide / manifold (*4)	Check / replace						10-13	
CONTROL SYSTEM								
Shift/throttle link/cable (F/FL200F)	Check / adjust / replace		•	•			10-17	
YDIS (*5)	Check			•				
Yamaha meter / gauge (Resetting maintenance intervals) Lan and Premium Lan	Check See "6Y8 and 6Y9 set up manual"		•	•				
POWER TRIM AND TILT								
PTT unit	Check / adjust / replace		•	•			10-16	

[illegible]