



Engine number:
Hours of operating:

F30B F40F		09-		YAMAHA MAINTENANCE CHART				
Item	Actions	Initial		Every			Ref. page service manual	OK ✓
			(20 h)	Every 1year (100 h)	3 year (300 h)	5 year (500 h)		
TOP COWLING								
Cowling clamp	Check			•			10-14	
FUEL SYSTEM								
Fuel hoses (high / low pressure)	Check / replace		•	•			6-1	
Fuel pump	Check / replace				•		6-13	
Fuel filter engine (water separator)	Check / replace		•	•			6-10	
POWER UNIT								
Engine oil	Replace API: SE,SF,SG,SH,SJ, or SL SAE 5W-30, 10W-30, 10W-40 Amount: Without filter 1,5 liter With filter 1,7 liter		•	•			10-9	
Oil filter	Replace			•			10-10	
Timing belt (*1)	Check / replace			•			7-12	
Engine idle speed / noise	Check		•	•			10-4	
Starting condition / noise							10-9	
Valve clearance	Check / adjust Intake: 0,20 ± 0,05 mm Exhaust: 0,30 ± 0,05 mm					•	7-2 7-4	
Spark plugs	Check / replace NGK DPR6EB-9			•			7-42	
Thermostat	Check / replace			•			7-49	
Fuel / oil leakage	Check		•	•			6-1	
Exhaust guide / manifold (*4)	Check / replace						9-33	
CONTROL SYSTEM								
Yamaha instruments (Resetting maintenance intervals) Lan	Check See "6Y8 multifunktion meter set up manual"		•	•				
Throttle / shift cable and links	Check / adjust / replace		•	•			3-14 10-5 6-21	
POWER TRIM AND TILT								
Power trim	Check / replace		•	•			10-13	

Item	Actions	Initial		Every			Ref. page Service manual	OK ✓
			(20 h)	Every 1year (100 h)	3 year (300 h)	5 year (500 h)		
LOWER UNIT								
Gear oil	Replace SAE 90,API GL-4/5 Amount:430 cm³		•	•			10-11	
Impeller (*3)	Check / replace			•	•		8-5	
Pilot water / water inlet	Check		•	•			10-8	
Lower unit	Pressure test			•			8-19	
Propeller / propeller shaft	Check / replace / grease		•	•			8-3	

GENERAL								
Anodes	Check / replace							
	External			•			8-3 9-40 9-43	
	Cylinder head			•			7-42	
	Exhaust cover and guide (replace)					•	7-49 9-33	
Battery	Check / replace / charge		•	•			10-3	
Wiring harness connections and coupler connections	Check / replace		•	•				
Engine start / shut-off switch	Check / replace		•	•			10-4	
Bolts and nuts, also for steering (*2)	Check / tighten		•	•			-	
Greasing points	Lubricate		•	•			10-12	
NOTES: (*1) Replace Timing belt every 1.000h / 5.year (*2) Not cylinder head and crank case bolts (*3) Replace Impeller every 300h / 3 year (*4) Every 1.000 hours IMPORTANT! Ref: service manual 6BG-28197-3L-11 Always check servicemanual and TSI for information!		----- DEALERS STAMP AND SIGNATURE						