



Engine number:

Hours of operating:

**F25D  
FT25F**

**09-**

## YAMAHA MAINTENANCE CHART

| Item                                                        | Actions                                                                                                                         | Initial |        | Every                    |                     |                     | Ref.<br>page<br>service<br>manual | OK<br>✓ |
|-------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------|---------|--------|--------------------------|---------------------|---------------------|-----------------------------------|---------|
|                                                             |                                                                                                                                 |         | (20 h) | Every 1year<br>( 100 h ) | 3 year<br>( 300 h ) | 5 year<br>( 500 h ) |                                   |         |
| TOP COWLING                                                 |                                                                                                                                 |         |        |                          |                     |                     |                                   |         |
| Cowling clamp                                               | Check                                                                                                                           |         |        | •                        |                     |                     | 10-15                             |         |
| FUEL SYSTEM                                                 |                                                                                                                                 |         |        |                          |                     |                     |                                   |         |
| Yamaha fuel tank                                            | Check / clean                                                                                                                   |         | •      | •                        |                     |                     | -                                 |         |
| Fuel pump                                                   | Check / replace                                                                                                                 |         |        |                          | •                   |                     | 6-6                               |         |
| Fuel filter engine (water separator)                        | Check / replace                                                                                                                 |         | •      | •                        |                     |                     | 6-4                               |         |
| POWER UNIT                                                  |                                                                                                                                 |         |        |                          |                     |                     |                                   |         |
| Engine oil                                                  | Replace<br>API: SE,SF,SG,SH,SJ, or SL<br>SAE 5W-30, 10W-30, 10W-40<br>Amount: Without filter 1,4 liter<br>With filter 1,6 liter |         | •      | •                        |                     |                     | 10-10                             |         |
| Oil filter                                                  | Replace                                                                                                                         |         |        | •                        |                     |                     | 10-12                             |         |
| Timing belt (*1)                                            | Check / replace                                                                                                                 |         |        | •                        |                     |                     | 7-21                              |         |
| Engine idle speed / noise                                   | Check                                                                                                                           |         | •      | •                        |                     |                     | 10-10                             |         |
| Starting condition / noise                                  |                                                                                                                                 |         |        |                          |                     |                     | 10-4                              |         |
| Valve clearance                                             | Check / adjust<br>Intake: 0,20 ± 0,05 mm<br>Exhaust: 0,30 ± 0,05 mm                                                             |         |        |                          |                     | •                   | 7-2                               |         |
| Spark plugs                                                 | Check / replace                                                                                                                 |         |        | •                        |                     |                     | 7-45                              |         |
| Spark plug caps / wires                                     | NGK DPR6EB-9                                                                                                                    |         |        |                          |                     |                     | 5-11                              |         |
| Thermostat                                                  | Check / replace                                                                                                                 |         |        | •                        |                     |                     | 7-52                              |         |
| Fuel / oil leakage                                          | Check                                                                                                                           |         | •      | •                        |                     |                     | 6-1                               |         |
| Exhaust guide / manifold (*4)                               | Check / replace                                                                                                                 |         |        |                          |                     |                     | 9-34                              |         |
| CONTROL SYSTEM                                              |                                                                                                                                 |         |        |                          |                     |                     |                                   |         |
| Yamaha instruments<br>(Resetting maintenance intervals) Lan | Check<br>See "6Y8 multifunktion meter set up manual"                                                                            |         | •      | •                        |                     |                     | -                                 |         |
| Throttle / shift cable and links                            | Check / adjust / replace                                                                                                        |         | •      | •                        |                     |                     | 3-13<br>6-15<br>10-5              |         |
| POWER TRIM AND TILT                                         |                                                                                                                                 |         |        |                          |                     |                     |                                   |         |
| Power trim                                                  | Check / replace                                                                                                                 |         | •      | •                        |                     |                     | 10-15                             |         |

