



Owner:

Engine hours:

Engine id:

VF150/175LA/XA

YAMAHA MAINTENANCE CHART

Item	Remarks	Initial		Every			Ref. page service manual	OK ✓
			20h	100h Every 1 year	300h 3 year	500h 5 year		
TOP COWLING								
Cowling lock lever and water leakage	Check			•			10-22	
FUEL SYSTEM								
Fuel hoses (high / low pressure)	Check / replace			•				
Fuel filter engine (water separator)	Check / replace		•	•			6-9	
Fuel filter (after vapor separator)	Check / replace			•			6-11	
Fuel pump	Check / replace				•		5-26	
POWER UNIT								
Ignition coils / ignition coil leads	Check / replace		•	•			5-33	
Engine oil	Replace API: SE,SF,SG,SH,SJ eller SL SAE 5W-30,10W-30, 10W-40 Amount: Without filter 4,3 liter With filter 4,5 liter		•	•			10-7 10-10	
Oil filter	Replace			•			10-16	
Oil control valve filter	Replace					•	7-49	
Timing belt (*2)	Check / replace					•	7-22	
Valve clearance	Check / adjust Intake: 0,17 - 0,24 mm Exhaust: 0,31 - 0,38 mm					•	7-2	
Spark plugs	Check / replace NGK LFR6A-11			•			7-29	
Thermostat / PCV	Check / replace			•			7-63	
Engine starting condition / engine idle speed / noise	Check		•	•			10-13	
Fuel / oil leak	Check / replace		•	•			2-20	
Exhaust guide / manifold (*4)	Check / replace						9-22	
CONTROL SYSTEM								
Shift/throttle link/cable (F/FL200F)	Check / adjust / replace		•	•			3-7	
YDIS (*5)	Check			•				
Yamaha meter / gauge (Resetting maintenance intervals) Lan and Premium Lan	Check See "6Y8 and 6Y9 set up manual"		•	•				
POWER TRIM AND TILT								
PTT unit	Check / adjust / replace		•	•			10-20 10-21	

Item	Remarks	Initial		Every			Ref. page Service manual	OK ✓
			20h	100h Every 1 year	300h 3 year	500h 5 year		
LOWER UNIT								
Gear oil	Replace SAE 90/API GL-4 Amount:980 cm³ Counter rotation:980 cm³		•	•			10-13	
Pilot water / water inlet	Check		•	•			10-13	
Impeller (*1)	Check / replace			•	•		8-7	
Propeller / propeller shaft	Check / replace / grease		•	•			8-5 8-1 8-3	
GENERAL								
Battery	Check / replace / charge		•	•			10-7	
Anodes External	Check / replace			•			7-49 9-34	
Anodes Cylinder head / exhaust passage	Check / replace			•			7-61	
Anodes cylinder head, cylinder block thermostat portion, oil cooler cover and exhaust guide	Replace					•	7-66 7-70	
Wiring harness connections and coupler connections	Check / replace		•	•				
Engine start switch, main switch, engine start / stop button, engine shut-off switch	Check / replace		•	•			5-37 5-39	
Bolts and nuts, also for steering (*3)	Check / tighten		•	•				
Greasing points	Grease		•	•			10-18	
NOTES: (*1) Replace Impeller every 300h / 3 year (*2) Replace timing belt after 1.000h / 5 year (*3) Not cylinder head and crank case bolts (*4) Check / replace after 1.000h (*5) Remember to input service record IMPORTANT! Ref: service manual 6DA-28197-H1-11 Always check service manual and TSI for information!		----- DEALERS STAMP AND SIGNATURE						