



# YAMAHA

Owner:

Engine hours:

Engine id:

**F50H / F60F  
FT50J / FT60G**

## YAMAHA MAINTENANCE CHART

Item	Remarks	Initial		Every			Ref. page service manual	OK ✓
			20h	100h Every 1 year	300h 3 year	500h 5 year		
<b>TOP COWLING</b>								
Cowling lock lever	Check			•			10-17	
<b>FUEL SYSTEM</b>								
Fuel hoses (high / low pressure)	Check / replace			•				
Fuel filter engine (water separator)	Check / replace		•	•			10-13	
Fuel pump	Check / replace				•		10-13	
Fuel tank (Yamaha portable)	Check / clean / replace			•			5-27	
<b>POWER UNIT</b>								
Ignition coils / ignition coil leads	Check / replace		•	•				
Engine oil	Replace <b>API: SE,SF,SG,SH,SJ eller SL</b> <b>SAE 5W-30,10W-30, 10W-40</b> Amount: Without filter 1,9 liter With filter 2,1 liter		•	•			10-10 10-11	
Oil filter	Replace			•			10-13	
Timing belt (*2)	Check / replace			•			10-17	
Valve clearance	Check / adjust <b>Intake: 0,15 - 0,25 mm</b> <b>Exhaust: 0,25 - 0,35 mm</b>					•	10-18	
Spark plugs	Check / replace <b>NGK DPR6EB-9</b>			•			10-17	
Thermostat	Check / replace			•			10-17	
Engine starting condition / engine idle speed / noise	Check		•	•			10-10	
Fuel / oil leak	Check / replace		•	•			10-14	
Exhaust guide / manifold (*4)	Check / replace						10-13	
<b>CONTROL SYSTEM</b>								
Shift / throttle link / cable	Check / adjust / replace		•	•			10-17	
YDIS	Check			•				
Yamaha meter / gauge (Resetting maintenance intervals) Lan	Check See "6Y8 set up manual"		•	•				
<b>POWER TRIM AND TILT</b>								
PTT unit	Check / adjust / replace		•	•			10-16	

Item	Remarks	Initial		Every			Ref. page Service manual	OK ✓
			20h	100h Every 1 year	300h 3 year	500h 5 year		
<b>LOWER UNIT</b>								
Gear oil	Replace <b>SAE 90/API GL-4</b> <b>F50H / F60F :430 cm<sup>3</sup></b> <b>FT50J / FT60G :670 cm<sup>3</sup></b>		•	•			<b>10-14</b>	
Pilot water / water inlet	Check		•	•			<b>10-9</b> <b>10-10</b>	
Impeller (*1)	Check / replace			•	•		<b>10-18</b>	
Propeller / propeller shaft	Check / replace / grease		•	•			<b>10-16</b>	
<b>GENERAL</b>								
Battery	Check / replace / charge		•	•			<b>10-9</b>	
Anodes External	Check / replace			•			<b>10-9</b>	
Anodes Cylinder head / exhaust cover	Check / replace			•			<b>10-9</b>	
Anodes (exhaust cover, cooling water passage cover, rectifier/regulator cover)	Replace					•	<b>10-9</b>	
Wiring harness connections and coupler connections	Check / replace		•	•				
Engine start switch, main switch, engine start / stop button, engine shut-off switch	Check / replace		•	•			<b>10-13</b>	
Bolts and nuts, also for steering (*3)	Check / tighten		•	•				
Greasing points	Grease		•	•			<b>10-15</b>	
<p><b>NOTES:</b>  (*1) Replace Impeller every 300h / 3 year  (*2) Replace timing belt after 1.000h / 5 year  (*3) Not cylinder head and crank case bolts  (*4) Check / replace after 1.000h</p> <p><b>IMPORTANT!</b>  Ref: service manual 6C1-28197-3S-11  Always check service manual and TSI for information!</p>		<p>-----  DEALERS STAMP AND SIGNATURE</p>						